

JD 1780 FRONT FOLD PLANTER

Equipped with no options

Model No's to Order for each planter configuration

			Quantity to order for each planter			
			12 Row 30" or 23 Row 15"	16 Row 30" or 31 Row 15"	16 Row 22"	24 Row 20"
Unit Mounted	2959-003 (2" offset fert. injection)		12/23	16/31	16	24
Liquid Fertilizer Coulter	w/ 2967-180B (Residue Manager for 2959-003) Optional or 2962-003A and 2962-004A RUMDDFO w/ 2962-005B (Residue Manager for 2962-003A/-004A) Optional or 2968-020B-R-LB/-L-LB Row Unit mount fits 1700, 7200 & 7300 & 2968-132 10" wheel assembly		N/A	N/A	N/A	N/A
2960 UNIT MOUNTED CONSERVATION COULTERS ONLY	2960-034 Coulter w/ U.N.T. bracket** or 2960-127 (coulter only)**		6 & 6 12	8 & 8 16	8 & 8 16	12 & 12 24
CLEAN UP CREW ONLY	2940-001B Pneumatic assembly or 2967-028A Universal unit mounted residue manager or 2967-029B Short U.N.T. or 2967-052A Screw Adjust (Short arm) or 2967-057A Screw Adjust (Long arm) or 2967-081A (R.M. attachment for JD tool hanger)**		12	16	N/A	N/A
Combination Attachments	2940-002B Pneumatic assembly narrow row or 2967-013B Short Narrow U.N.T. or 2967-048A Narrow row unit mounted residue manager or 2967-054A Narrow row Screw Adjust (short arm) or 2967-056A Narrow row Screw Adjust (long arm) 2967-007A U.N.T. Residue manager kit or 2967-035A Titan Universal or 2967-042B Titan residue manager for JD Coulter or 2967-115A (for use with 2960-127 coulter)** 2967-070 (Quick adjust kit) Optional		23 12 11	31 16 15	16 16	24 24
			12^	16^	N/A	N/A

**Blade Choices refer to price book.

** 30" minimum row spacing only

*** 15"/20",22" row spacing

^ Two row units (30" spacing) near lift wheels need 21" long parallel arms