

# CASE/IH 1200 STACKER BAR/ NEW HOLLAND SP380 MOUNTED STACKER PLANTER

8 Row Wide, 12 Row Narrow and Wide

<i>Model No.'s to Order for each planter configuration</i>			<i>Quantity to order for each planter</i>	
			<b>8R N/W 36", 38" 40"</b>	<b>12 R N/W 30", 36", 38", 40"</b>
<b>LIQUID FERT. COULTERS ONLY</b>	2995-046-L and 2995-046-R^ Front Bar Kit required (Call Yetter for price & details)		<b>4 and 4 \$</b>	<b>6 and 6 \$</b>
<b>Cannot be used with any unit mounted attachments</b>				
<b>DRY FERT. COULTERS ONLY</b>	<b>NOT AVAILABLE</b>			
<b>2960 UNIT MOUNTED CONSERVATION COULTERS ONLY</b>	2960-020 (unit coulters only) or 2960-020-MW (unit coulters only with 25 wave blade)	Choice of one style	<b>8</b>	<b>12</b>
<b>CLEAN UP CREW ONLY</b>	2965-021 (13" Notched blade) or 2965-023 Screw Adjust Trashmaster or 2965-106 (12" solid blade) or 2967-036 Narrow row residue manager or 2967-044-L or R Notched Screw Adjust or 2967-053 Screw Adjust residue manager or 2967-055 Narrow Row Screw Adjust residue manager or 2967-090 Floating narrow residue manager or 2967-097 Short titan residue manager or 2967-106 (13" steel wheel)		<b>8</b>	<b>12</b>
<b>COMBO ATTACHMENT</b>	2961-011 Cut-n-Move 2967-008 Titan (for use with 2960-020 coulters)		<b>8</b>	<b>12</b>
<b>FRAME MOUNTED COULTERS ONLY</b>			<b>N/A</b>	<b>N/A</b>
<b><u>DOUBLE COULTERS</u> Fertilizer</b>	2995		<b>N/A</b>	<b>N/A</b>

\$Modified 2995-056 Call Yetter for price and details

Important: Fertilizer coulters mounted on 30" row spacing, special attention needs to be given to the clearance between the tractor's rear tires and their fertilizer coulters.

^ Fertilizer placements available are : L & R = left & right standard rear knife, LS & RS = left & right side profile knife

LIHD & RIHD = left & right hand injection (tips not included). See Glossary for illustrations.